



**INSTALLATION NOTE**

Monarfloor Tranquility®, must be laid tight to all perimeters. The product is bonded to the sub-floor with the self-adhesive backing. Joints should be but jointed and the integral overlap joint taped or adhered. The finished timber or laminate floor can then be installed in accordance with the manufacturers instructions. The finished floor must not be fixed and laid as a floating floor over Monarfloor Tranquility®.

Project: <b>Monarfloor Tranquility® Soft Bond</b>	
Title: <b>Typical Precast Concrete Plank with Screed</b>	
Drawn: <b>LN</b> Scale: <b>NTS</b>	
Date: <b>July 2008</b>	
<b>Monarfloor® Acoustic Systems</b>	
IC01588 - Issue 4	